

INSTRUCTIONS ON HOW TO CONNECT A PROJECTOR TO A LAPTOP

STEP 1. Ensure both devices are turned off. Connect VGA cable (shown right) to the Laptop in the Output VGA/RGB slot. If you are using a Apple Mac ensure the correct VGA adapter is connected.



Connect the other end to the projector in the 'input A' slot. If there is more than one RGB slot on the projector ensure the video mode is set to the matching input slot (use the remote to change).

STEP 2. Turn both devices on. The Projector will usually, automatically pick up the image from the laptop depending on your operating system. If the Projector hasn't picked up your laptop please follow step 3.

STEP 3. FOR PC Hold the function key (FN) usually found by the CTRL and ALT key then push the Projector/TV key. The diagram displayed (right) shows some of the different pictures the Projector/TV key can have



FOR MAC Click the Apple button in the top left hand corner, go system preferences, then displays then click 'detect displays' and ensure mirror displays is ticked under the arrangement section.

STILL NOT DISPLAYING AN IMAGE?

Ensure your computers screen resolution is on a compatible size with the projector. CX-21 (Boardroom Projector) – Maximum screen resolution on the computer is 1280x1024 Pixels. CW-125 (Conference projector) Maximum screen resolution on the computer is 1400x1050 Pixels

If you have any other problems or questions please don't hesitate to call us!